

---

## Quick Guide

---

# XK series

The purpose of this Quick Reference Guide is to familiarise the driver with the layout of the Jaguar XK series controls.




### Tyre Pressures for XK8 and XKR *See also Vehicle Care Handbook, Section 6*

Wheel size/type		Maximum comfort - Speeds up to 160 km/h (100mph)	Normal Pressures
17 and 18 inch	Front	180 kPa (1.8 kg/cm <sup>2</sup> , 1.8 bar, 26 lbf/in <sup>2</sup> )	220 kPa (2.24 kg/cm <sup>2</sup> , 2.2 bar, 32 lbf/in <sup>2</sup> )
	Rear	190 kPa (2.0 kg/cm <sup>2</sup> , 1.9 bar, 28 lbf/in <sup>2</sup> )	230 kPa (2.4 kg/cm <sup>2</sup> , 2.3 bar, 34 lbf/in <sup>2</sup> )
Temporary-use spare			410 kPa (4.2 kg/cm <sup>2</sup> , 4.1 bar, 60 lbf/in <sup>2</sup> )

## Driver's controls, switches and features

Page numbers refer to Driver's Handbook.

1. Garage door opener switches, page 4-25.
2. Map light switch, page 3-28.
3. Interior rear view mirror, page 4-6.
4. Instruments and warning lights, page 3-1 and 3-3.
5. Message centre display, page 3-8.
6. Trip computer switchpack, page 3-13.
7. Windscreen wipers and washers, headlamp powerwash switches, page 3-30 and 3-31.
8. Cruise control switches, page 3-19.



9. Drivers airbag and horns, page 4-18 and 3-32.
10. Audio controls, See Audio System Handbook.
11. Valet switch, page 2-7.
12. Fuel flap release switch, page 4-10.
13. Luggage compartment remote release switch, page 2-7.
14. Exterior lighting, direction indicator and trip cycle switches, page 3-25, 3-27 and 3-12.
15. Instruments, clock and warning lights, or Navigation system control panel and screen, page 3-2 and 3-3 or Navigation System Handbook.
16. Climate control system control panel, page 6-1.
17. Hazard warning switch, page 3-27.
18. Front seat heater switch, page 4-2.





19. Sport mode switch, page 3-15.
20. Cruise control master switch, page 3-19.
21. Roof and rear quarter window switch (convertible only), page 8-1 and 8-2.
22. Audio system and telephone control panel, See Audio System Handbook.
23. Rear fog lamps switch, page 3-27.
24. Front fog lamps switch, page 3-27.
25. Traction control switch, page 3-21.
26. Heated front screen switch, page 6-3.
27. Heated rear screen switch, page 6-3.

Page numbers refer to Driver's Handbook.

For more in-depth information the driver should study the Driver's Handbook, with particular reference to all **WARNINGS** and **Cautions**.




**Key-ring Transmitter,**  
page 2-4.

-  Lock.
-  Un-lock.
-  Headlamp convenience.
-  Luggage compartment release.


**Vehicle Security,**  
Driver's Handbook page 2-1.



All page numbers refer to the  
Driver's Handbook



**Ignition/Starter  
Switch and  
Steering Lock,**  
page 4-7.




**Driver's Door Switch Pack,**

1. Door mirror adjustment switch, page 4-5.
2. Window operation switches, page 3-22.




**Steering Column Adjustment,**  
page 4-4




**Seat Adjustment  
Switches, page 4-1.**


1. Seat cushion position.
2. Seat back angle.
3. Lumber support.



**Driving Position Memory  
Buttons, page 4-3.**



**Front Seat Back  
Tilt, page 4-2.**




**Seat Belts,**  
page 4-15 and 4-17.



**Front Seat Belt  
Height Adjustment  
(coupe only), page 4-16.**




**Bonnet Release,**  
See Vehicle Care Handbook.



## Luggage Compartment Release, page 2-7.

### Luggage Compartment Layout,

- 1 Literature pack which includes Vehicle Care Handbook.
- 2 Spare wheel and wheel changing equipment, See Vehicle Care Handbook Section 4.
- 3 Battery, See Vehicle Care Handbook Section 5.




### Fuses, See Vehicle Care Handbook, Section 4.



### Bulb Changing, See Vehicle Care Handbook, Section 5.

### Fuel and refuelling, page 4-10.



- **Underbonnet Servicing,** See Vehicle Care Handbook, Section 3.
- **Wheel Changing and Jacking,** See Vehicle Care Handbook, Section 4.